Upgrading software

Correct installation of updated software is through com cable connecting the com mouth of the computer. (You don't need to open the power of the memo scanner.)

1. Run UIF-ISP, there will be the interface as follows

🙀 UIF_ISP.exe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port	Message Window This soft is only for UIFTECH MEMOSCANNER HOW TO USE
Step2:Open file(.uif)	Step1:Connect the electric cable with COM, but please DON'T POWER ON memoscanner. Then select COM port. Step2:Open the file(.uif) what you need. Step3: After press the update button, Then power on memoscanner.
Step3:Drop the button, Then power on	When the message window shows 'program successful!', It shows you are successful to update the memoscanner. If it shows 'program error,please reprogram!', So you need to update again.
Step4:Close the soft and quit	

2. Select the com port

UIF_ISP.exe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port	Message Window This soft is only for UIFTECH MEMOSCANNER HOW TO USE Step1:Connect the electric cable with COM, but please DON'T POWER ON memoscanner. Then select COM port. Step2:Open the file(.uif) what you need. Step3: After press the update button, Then power on memoscanner. When the message window shows 'program successful!', It shows you are successful to update the memoscanner. If it shows 'program error, please reprogram!', So you need to update again.
Quit	

3. Press "Open File" button, select the file for update(expand: .uif)

🔀 UIF_DPLexe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port COM1 COM1 HOW TO USE	MOSCANNER
open *.uif 2 X Step2:Open file(.uif 查找范围①: Comyfile	with COM, but :. Then select COM
Open F 🖬 423.uif 🖬 u.uif I HV31.uif I JIANBAN.uif	ou need. :ton, Then power on
Step3:Drop the button III TEST1.uif	cogram iccessful to update ogram error,please
Upda 打开 (0) 文件名 (0): 打开 (0)	e again.
Step4:Close the soft	
Quit	-

4. Press "update", open the power of memo scanner, there will be the interface as follows. The Memo scanner is trying to connect with PC.

💑 UIF_ISP.exe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port	Message Window We are connecting
Step2:Open file(.uif)	
Step3:Drop the button, Then power on	
Step4:Close the soft and quit	
L	

4-1. the blow interface will appear if the connection is success.

UIF_ISP.exe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port	Message Window We are connecting
	We are Programing
_Step2:Open file(.uif)	
Open File	
-Step3.Drop the button Then power on	
Update	
Step4:Close the soft and quit	
Quit	

4-2. If the connection is fail, this time requests to close the power of memo scanner and check whether the connection and the choice of COM mouth are right or not.

UIF_ISP.exe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port	- Message Window We are connecting
Step2:Open file(.uif) Open File Step3:Drop the button, Then power on	Communication is failure! NOTICE: Step1: Connect the electric cable with right COM, but please DON'T POWER ON. Step2: Drop the button of update. Step3: Power on your memoscanner.
Step4:Close the soft and quit	

5. Connections succeed, upgrading starts.

UIF_ISP.exe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port	Message Window We are connecting
Step2:Open file(.uif)	We are Programing
Step3:Drop the button, Then power on Update	
Step4:Close the soft and quit	
Quit	

5-1. If the below interface appears in the process of upgrading, that's to say the communications failures, this time requests to close the procedures and re-run the programmer

🔀 UIF_ISP.exe Ver1.0 http://www.memosea	reu 🛪
Step1:Select right COM Port	Message Window We are connecting
Step2:Open file(.uif)	We are Programing
	Communication error!
-Step3:Drop the button,Then power or	Please press this key to quit soft, run it again!
Update	确定
Step4:Close the soft and quit Quit	

6. Update successful

😹 UIF_ISP.exe Ver1.0 http://www.memoscan.cn	×
Step1:Select right COM Port	Message Window We are connecting 📂 connect ok
Step2:Open file(.uif) Open File	We are Programing program over! Program successful!
Step3:Drop the button, Then power on Update	
Step4:Close the soft and quit	

6-1. If the below interface appears, that's to say the upgrading failure. This time requests to close the power of memo scanner and back to step 1 to re-upgrading.

or_prexe verio http://www.inemoscan.cn	
Step1:Select right COM Port	Message Window We are connecting
	We are Programing
Step2:Open file(.uif)	program over!
Open File	Program error, please reprogram!
Step3:Drop the button, Then power on	
Update	
Step4:Close the soft and quit	
Quit	