

Manufacturing Work Bench installation

1. Create a temporary folder on the primary hard disk (ie. C:\AATemp)
2. Save the attached MfgWB.az-ZIP file as **MfgWB.ZIP** in the folder
3. Unzip (extract) all files into the temporary folder

MfgWB_Users_Guide.pdf ----- Manufacturing Work Bench Users Guide
SETUP.EXE ----- MfgWB setup application
MfgWB.CAB ----- MfgWB setup data cabinet
SETUP.LST ----- Setup data file list
SETUP.LSX ----- Alternate setup data file list

4. Save the **MfgWB.zip** file and delete it from the temporary folder
5. **Exit / Stop** all other applications
6. Double-click **SETUP.EXE** (7 files will load)

NCData Services - Manufacturing Work Bench Setup application starts

(Note: If setup can not start because system files are out of date
select **Cancel** and rename the alternate **SETUP.LSX** to **SETUP.LST**
and restart **SETUP.EXE**)

7. Select **OK**
8. Select **ICON** button to install MfgWB (in C:\Program Files\MfgWB)
or (in C:\Program Files(x86)\MfgWB)
9. Select **Continue** to program group
(Application files will install (status bar) in about 10 seconds)
10. Select **OK** when setup completed successfully

MfgWB Installation is now complete

(If **AZpost** postprocessor(s) are not already installed, They must be
installed now before starting Manufacturing Work Bench)

To postprocess an APTsource file (installation verification)

11. Select **START** from bottom left windows tool bar

12. Select **ALL Programs**

13. Select **NCData Services - Manufacturing Work Bench**

(Note: A **desktop shortcut** can be created to **C:\Program Files\MfgWB.EXE**)

14. Select APTsource program (ie. **PPTEST3X.apr**) from APTsource list box

15. Select **Edit** button

A command window should open aprsource file using Wordpad
(if not see customizing USEREDIT.BAT in MfgWB_Users_Guide)

16. **Exit** Wordpad

17. Select postprocessor executable (ie. **VMC3X.EXE**) from Postprocessor list box

18. Select **Postprocess** button

19. Select **OK** in File & Postprocessor pop-up box

A command window should execute the **VMC3X** postprocessor using **PPTEST3X.apr** as input to a Successful Termination.

20. Save this document "MfgWB_Installation.pdf" in C:\AZpost\doc folder